

HOTSEC site monitor plugin manual

v. xx.xx.2019



Note: This manual is for end-users. Prior to program use all the software components must be installed and hardware configuration must be done. Please refer to "Hotsec installation" and "Hotsec setup" manuals to set up the system first.

Purpose	3
Licensing	3
Setup	3
Usage	4

Purpose


The purpose of Hotsec site monitor is to monitor which persons are inside a building or other predefined area (site) in real time based on their movements through internal and exit doors. It is also possible to use site monitor to automatically arm predefined partitions when last person leaves the building or other area (site).

Licensing


Hotsec site monitor is licensed as extra module for Hotsec client. License limits how many site monitor sites can be created in one Hotsec system (server).

Setup

Site monitor setup is under "Site monitor" in Hotsec system settings.




First you have to create a new site by right clicking on empty space and entering a name for new site.



Next you can define:

- Auto arming - enabled or disabled. Arms the defined partition(s) when last person leaves the site
- Departments involved
- Doors. Entry and exit doors to the site.
- Partitions which will be automatically armed when last person leaves the site.



To save changes you need to press the green “save” button



Usage

Hotsec demo server [hot]

Application **Object** Tools Help

Time	Object	Event
09.01.1	admin	SQL command executed
04.02.08	ni perenimi1	Back door
04.02.08	elle	Back door
04.02.08	asutaja	Back door
04.02.08	asutaja	Main door
04.02.08	ni perenimi5	Main door
04.02.08	ni perenimi1	Back door
04.02.08	asutaja	Main door
04.02.08	Elset	Main door
04.02.07:43:47	Aivo Lelle	Back door
04.02.07:00:44	eesnimi perenimi4	Back door
04.02.06:39:55	Jurijs Elset	Main door

Here is the sample of site monitor view

User name	Entry time	Stay time	Last door	Last time
Site name : Test Site				
Aivo Lelle	11:53	195:16:00	Back door	08:49
Cleaners Card	06:20	200:49:00	Back door	12:05
Hot Sec	07:06	200:02:00	Main door	14:42
Jurjjs Elset	08:22	198:46:00	Main door	08:18
Keypad Account	09:00	198:08:00	Main door	14:50
Test Admin	11:01	196:08:00	Main door	14:12
Test Kasutaja	10:51	196:17:00	Back door	08:42
eesnimi perenimi1	07:43	199:26:00	Back door	08:54
eesnimi perenimi2	08:49	198:19:00	Back door	10:38
eesnimi perenimi2	08:39	198:30:00	Main door	14:55
eesnimi perenimi4	08:58	198:11:00	Back door	07:00
eesnimi perenimi5	08:42	198:27:00	Main door	08:36


Options Refresh Clear selected site Print Close

Here you can see

- User name who is in site
- Entry time to the site
- Stay time (displayed red if over 8 hours)
- Last door used
- Last time means the time when any door used (not just defined entry or exit doors but any door within the system)

To remove the users from the list there are 4 ways:

1. Users uses card on exit point
2. Operator can remove users from the list by selecting user and hitting the delete button on keyboard
3. Hit the “Clear selected site” button to remove all users from the list
4. Paradox event “no movement auto arming” on defined partition also clears the list



From options there are “automatic table refresh” and “Print users when fire alarm” which means that current list of users on site will be sent to Windows default printer when fire alarm event occurs in the log.