PIN

[Ok]

[Menu]

0 Area Control

[Menu]

Logged off menu items

1 Quick Review

2 Info

3 Time

Installer enabled option

Installer only menu

Keypad entry

1 Info | 0/1 Review | 2 Locate User | 3 Read Analogue | 4 Read Count | 5 Input States | 6 Read Volts | 7 Read Num Users | 8 Modules | 9 Panel

2 Access | 1 User Codes | 2 User Groups | 3 Lists | 4 Groups | 5 Card Formats | 6 Backup Cards | 7 RF Remotes | 0 More

- 4 Groups: 1 Menu | 2 Door Type | 3 Process | 4 Interlocks | 5 Qual Dtypes
- 3 Lists: 1 Areas | 2 Doors | 3 Tel Numbers | 4 Floors | 5 Lifts | 6 Auxes
- 0 More: 0 Back | 1 Card Templates | 2 Fob Templates

3 Isolate

4 Testing | 1 Inputs | 2 Auxiliaries | 3 Sirens | 4 Telecom | 5 Cards | 6 Memory | 7 Ports | 8 Power | 9 Volts

5 Times | 1 Time & Date | 2 Time Periods | 3 Schedule | 4 Holidays | 5 LCD Messages

6 Misc | 1 Disable | 2 UK Reset

7 Installer — See installer programming menu structure.

DRAFT

8 Service | 1 Require Service | 2 Test Report | 3 Security | 4 Answer Phone

9 Control | 1 P Actions | 2 Doors | 3 | 4 Lifts | 5 | 6 Adjust Count | 7 Adjust Users | 8 Amnesty

- 2 Doors: 1 Door | 2 Door List