

128k Memory Configurations. V3.5

	128K Std	128K Access	128K Enlarged	128K Special	128K Alarms
Users	2000	1000	1000	1000	1000
User Names	100	1000	100	1000	200
User Types	32	64	32	64	48
Card Only Users	0	0	0	0	0
Areas	96	32	96	32	96
Doors	32	64	16	64	16
Lift Cars	3	6	3	4	3
Site Codes	6	5	6	6	5
TimeZones	32	32	32	32	32
Holidays	16	16	16	16	16
Diaries	10	10	10	10	10
Review Memory	2000	2000	2000	2000	2000
Counters	8	8	16	8	8
Area Lists	96	32	96	32	96
Doors Lists	48	64	32	64	32
Siren Lists	32	16	32	16	32
Floor Lists	24	48	24	48	24
Lift Car Lists	6	12	6	8	6
Auxiliary Lists	32	32	32	32	32
Menu Groups	8	8	16	8	16
Access Groups	16	16	16	16	8
Process Groups	32	32	32	32	32
Interlock Groups	16	32	12	32	8
Comms Tasks	6	6	6	6	8
Phone Numbers	8	8	8	8	12
DTMF Controls	16	16	16	16	16
Function Zones	32	16	32	16	32
Calculated Auxes	32	16	32	16	32
Home Auxiliaries	64	32	64	32	32
Home Zones	32	16	64	16	64
LCD Terminals	32	16	32	16	32
Expander 32Z	4	2	6	1	15
Expander 16Z	6	6	8	2	0
Reader Modules	16	32	8	8	8
Mini Expanders	5	4	10	16	4
Analogue Modules	2	4	4	4	4
Intelligent Readers	0	0	0	8	2
SpreadNet	2	2	8	2	4
AirCon Control	2	4	4	4	4

NOTE: Only Users with names have Expiry dates in the 128k Memory configurations.