

**512k Memory Configurations. V7.4 - V7.8** *Please read notes on p10.*

V7.4-V7.8 512k (4MBit)	Standard	Access	Enlarged	Apartments	Access 2	Special	Alarms	X Door	IP Door
	00	01	02	03	04	05	06	07	08
Users	4000	500	4000	2000	2000	4096	4000	4096	4096
User Names	4000	500	4000	2000	2000	2000	4000	100 (500)	100
User RF Fobs	50	50	100	100	50	50	50	50	0
Extra Door/DList for PINs	0	0	0	2000	0	0	0	4096	0
Extra Door/DList for Cards	0	0	0	0	0	0	0	20904	0
User Types	128	250	250	128	128	250	200	250	128
Card Only Users	0	24576	0	0	16384	8192	0	20904	43904
Areas	240 (250)	128	128	128	64	128	200	64	16
Doors	128	240	176	208	208	176	96	96	8
Lift Cars	8 (12)	16	16	8	16	16	12	12	0
Site Codes	16	16	32	8	16	16	16	8	8
TimeZones	64	64	64	64	32	64	96	64	64
Holidays	32	16	16	16	16	16	16	16	16
Diaries	24 (32)	32	32	16	16	32	16	16	16
Counters	16	16	32	128	16	16	16	16	4
Area Lists	240	128	128	128	128	128	200	64	128
Doors Lists	128	240	240	128	128	240	96	250	128
Siren Lists	128	64	64	32	16	64	64	16	1
Floor Lists	64 (96)	200	250	128	64	250	64	128	0
Lift Car Lists	12 (16)	32	48	16	16	64	16	16	0
Auxiliary Lists	32	32	32	32	16	32	80 (64)	16	8
Menu Groups	32	32	32	16	16	32	32	16	16
Access Groups	16 (32)	32	32	16	16	32	16	16	16
Process Groups	48 (64)	64	64	32	32	64	48	32	32
Interlock Groups	16	64	64	8	48	64	16	16	4
Comms Tasks	8	8	8	8	8	8	8 (10)	8	8
Phone Numbers	32	32	32	32	32	32	32	32	32
DTMF Controls	16	16	16	16	16	16	16	16	16
Function Zones	64	32	32	128	48	32	128	64	16
Calculated Auxes	64	32	64	128	32	32	64	64	32
Home Auxiliaries	96	128	128	128	64	128	128	32	16
Home Zones	32	32	128	32	32	32	48	32	16
Automation Auxiliaries	48	48	64	128	48	64	64	64	16
LCD Terminals	99	48	48	99	48	64	75	16	8
Touchscreen Terminals	8	8	8	32	8	8	8	4	2
Expander Modules 32Z	20	5	8	8 (4)	16	16	64	0	0
Expander Modules 16Z	44	20	24	8 (16)	0	16	0	16	0
Reader Modules	64	75	64	99	8	48	48	48	4
Mini Expander Modules	24	10	16	99	8	16	16	8	1
Analogue Modules	8	8	8	32	8	8	8	8	1
Intell 4Dr Access Modules	0	8	4	12	48	32	8	24	0
LAN Pwr Supply Modules	8	8	8	16	16	8	4	4	4
Wireless Network Modules	8	4	13	8	4	4	4	2	0
RF Expander Modules	4	4	8	16	4	4	8	2	0
AirCon Control	2 (4)	4	4	4	4	4	4	4	0
Review Memory. *	6500	6500	6500	6500	6500	6500	6500	6500	4000
EN Review: ^ Normal	5500	5500	5500	5500	5500	5500	5500	5500	3000
Mandatory	1000	1000	1000	1000	1000	1000	1000	1000	1000

\* Applies only to Non EN firmware types. See Note 7.

^ Applies only to EN firmware types. See Note 7.