HOTSEC Checkpoint plugin manual

v. xx.xx.2019

Note: This manual is for end-users. Prior to program use all the software components must be installed and hardware configuration must be done. Please refer to “Hotsec installation” and “Hotsec setup” manuals to set up the system first.

Purpose 3

Licensing 3

Setup 3

Usage 4

Purpose

The purpose of Hotsec checkpoint is to enable door monitoring for guard or other kind of operator. It can be configured so that the checkpoint window is just for displaying information about the person that used the door or it can be configured to require and wait for guards decision - grant or deny the access.

Licensing

Hotsec checkpoint is licensed by the number of checkpoint readers that can be active at the same time

Setup

Checkpoint on a reader is activated by right-clicking and checking the door on the drawing



Or from Object menu





Usage

Following window will popup when any user uses the reader marked as checkpoint.