



965001 Type 2 CE Controller

Field Instructions

Enhanced Transient Protection

Page 1 of 2

	Printed	23-Mar-04
	Date	by
Issue	23 March 2004	Brian

1. Introduction

Enhancement to CE Controller 965001 (PCB 935001), 1x 7K14 MOV connected across LAN "POS" and LAN "NEG", 1x 7K14 MOV connected across the "DET +" "DET -" output.


2. CAUTION

DO NOT break the epoxy on the component legs (i.e. DO NOT pry open the legs of the component.)

3. Component Legs

The legs of the MOV must be cut leaving just enough bare wire to insert fully into the terminal strip.

4. Terminal Block Location



MOV across the LAN
"LAN Neg" "LAN Pos"
terminals


MOV across the
"DET -" "DET +"
terminals



965001 Type 2 CE Controller
Field Instructions
Enhanced Transient Protection


Page 2 of 2

5. MOV on DET Terminals



The legs of the MOV must be cut leaving just enough bare wire to insert fully into the terminal strip.

6. MOV across LAN Terminals



The legs of the MOV must be cut leaving just enough bare wire to insert fully into the terminal strip.