

512k (4MBit) Memory Configurations. V5.1**(Also applicable to V3.5, V4 and V4.5 with the exceptions shown in brackets)**

V5 (V3.5 to V5.1) 512k (4MBit)	Standard	Access	Enlarged	Apartments V4.5 or later	Access 2 V4.5 or later	Special	Alarms	X Door NEW!
Users	4000	500	4000	2000	2000	4096 (4000)	4000	4096
User Names	4000	500	4000	2000	2000	2000	4000	500
User RF Fobs ‡	50	50	100	100	50	50	50	50
Extra Door/DList for PINs	0	0	0	2000	0	0	0	4096
Extra Door/DList for Cards	0	0	0	0	0	0	0	20904
User Types	128	250	250	128	128	250	200 (250)	250
Card Only Users *	0	24576	0	0	16384	8192	0	20904
Areas	250	128	128	128	64	128	200	64
Doors	128	240	176	208	208	176	96 (128)	96
Lift Cars *	12 (16)	16	16	8	16	16	12 (16)	12
Site Codes	16	16	32	8	16	16	16 (32)	8
TimeZones	64	64	64	64	32	64	96	64
Holidays	32	16	16	16	16	16	16	16
Diaries	32 (16)	32	32	16	16	32	16	16
Review Memory	6500	6500	6500	6500	6500	6500	6500	6500
Counters	16	16	32	128	16	16	16	16
Area Lists	240 (250)	128	128	128	128	128	200	64
Doors Lists	128	240	240	128	128	240	96 (128)	250
Siren Lists	128	64	64	32	16	64	64 (128)	16
Floor Lists *	96 (128)	200	250	128	64	250	64	128
Lift Car Lists *	16	32	48	16	16	64	16	16
Auxiliary Lists	32	32	32	32	16	32	64	16
Menu Groups	32	32	32	16	16	32	32 (64)	16
Access Groups	32	32	32	16	16	32	16 (32)	16
Process Groups	64 (128)	64	64	32	32	64	48 (64)	32
Interlock Groups *	16 (48)	64	64	8	48	64	16 (32)	16
Comms Tasks	8	8	8	8	8	8	10	8
Phone Numbers	32 (16)	32 (16)	32 (16)	32	32	32 (16)	32	32
DTMF Controls	16	16	16	16	16	16	16	16
Function Zones	64	32	32	128	48	32	128	64
Calculated Auxes	64	32	64	128	32	32	64	64
Home Auxiliaries	96 (128)	128	128	128	64	128	128	32
Home Zones	32 (64)	32	128	32	32	32	48 (128)	32
Automation Auxiliaries ^	48	48 (32)	64	128	48	64	64	64
LCD Terminals	99	48	48	99	48	64	75	16
Expander Modules 32Z	20	5	8	4	16	16	64	0
Expander Modules 16Z	44	20	24	16	0	16	0 (1)	16
Reader Modules	64	75	64	99	8	48	48	48
Mini Expander Modules	24	10	16	99	8	16	16	8
Analogue Modules	8	8	8	32	8	8	8	8
Intelligent 4Dr Access Modules	0	8	4 (2)	12	48	32	8	24
LAN Pwr Supply Modules	8 (0)	8 (0)	8 (0)	16	16	8 (0)	4 (0)	4
Wireless Network Modules	8 (13) †	4 †	13 (4) †	8 (13) †	4 †	4 †	4 (8) †	2
RF Expander Modules ‡	4	4	8	16	4	4	8	2
AirCon Control *	4	4	4	4	4	4	4	4

- NOTES: 1) Only Users with names have Expiry dates.
2) * Only available in Access 4000.
3) () Where values differ from the values in V3.5 through to V4.5, the old values are shown in brackets.
4) ^ “Automation I/F Auxiliaries” were formerly called “C-Bus Auxiliaries”.
5) † Requires Options Micro Chip upgrade to support more than 32 Inovonics Wireless Zones.
6) ‡ RF Expander Modules available in V5.1 or later only.